

Broil King®

Broil King®

BARON 420
8752-53NZ



















Broil King®


BARON 490
8752-83NZ




HARDWARE INCLUDED

S21124		(8)	Y-29304		(2)
Y-12865		(12)	Y-11793		(4)
Y-11551		(2)	Y-12124		(2)
56039-214A		(1)	Y-11230		(1)
Y-12229		(1)	32001-151		(4)
S21235		(2)	S21233		(2)
S21084		(8)	S21125		(2)
 <p>#2 ROBERTSON #3 ROBERTSON</p>					
20005-000					(1)





TOOLS REQUIRED




1




2





3

(2) 





4


(8)







5




6

(2) 




7


(2)




(1)





8



(2) 



9

(2) 







11

(4)


(1)

(1)






Broil King
BARBECUE

12





13







15



(4)










17

(6)










19








20






22







24




(2)



(2)





PARTS LIST / LISTE DES PIECES

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>8752-53NZ</u>	<u>8752-83NZ</u>
1	52005-107	FIREBOX ASSEMBLY	1	1
2	66005-301	LID ASSEMBLY	1	1
7	Y-11544S	SCREW - BURNER	4	4
8	S21242	BURNER CLIP	4	4
18	11241	GRID - SINGLE CI	4	4
20	52005-992	GRID - WARMING RACK	1	1
21	59805-014	CONTROL ASSEMBLY	1	•
	59805-074	CONTROL ASSEMBLY	•	1
22	22025-903A	COLLECTOR BOX	1	1
24	10111-16A	CONNECTOR HOSE	1	1
25	18631	BURNER	4	4
26	22001-769	CONTROL KNOB	4	4
26A	22001-669	CONTROL KNOB	•	2
27	22002-264	CONTROL BEZEL	4	4
27A	22001-164	CONTROL BEZEL	•	2
28	52005-814	CONTROL COVER	1	•
	52005-894	CONTROL COVER	•	1
31	52009-918	EDGE CAP - LH	1	1
32	52009-938	EDGE CAP - RH	1	1
34A	Y-11230	COTTER PIN	•	1
37	53139-908	SHELF BRACKET	4	4
38	Y-12620	SHELF LOCK CLIP	4	4
40	10111-HR06	HOSE AND REGULATOR	1	1
41	10342-E13	ELECTRODE	1	1
42	10342-E22	ELECTRODE	1	1
44	52005-001A	ELECTRONIC IGNITOR	1	•
	52005-007A	ELECTRONIC IGNITOR	•	1
44A	25070-925	WIRE - IGNITOR	1	1
44B	25070-93	BUTTON - IGNITOR	1	1
48	52004-007	GREASE PAN	1	1
49	51009-007	GREASE TRAY	1	1
50	52060-101	GREASE TRAY SUPPORT	1	1
51	18431	FLAV-R-WAVE ®	4	4
52	52149-004	GREASE SHIELD	3	3
56	24005-12A	HANDLE	1	1
58	54009-936	BEZEL	2	2
59	10081-BK630	NAMEPLATE	1	1
60	18013	HEAT INDICATOR	1	1
62	53409-138	SHELF END CAP	2	2
65	20005-000	MATCH LIGHT - STICK	1	1
68	51275-111A	DOOR	1	1
69	51275-131A	DOOR	1	1
70	21071-13	HANDLE	2	2
71	21070-13	BEZEL	4	4
78	56039-214A	MAGNET BRACKET	1	1
80	51189-101A	SIDE PANEL	2	2
82	51605-104	BASE TRIM	1	1
87	Y-11793	NUT 1/4-20	10	10
88	21305-921	PANEL - REAR	1	1
90	51625-131	BASE	1	1
99	32001-151	CASTOR BRACKET CAP	4	4
100	51639-108	CASTOR BRACKET	2	2
102	10892-286	CASTOR	4	4
103	21039-301	TANK BRACKET	1	1
113	10342-T14	SIDE BURNER ELECTRODE	•	1
114	53150-614	SHELF - RIGHT	1	1
115	53150-634	SHELF - LEFT	1	•
	53150-654	SHELF - SB - LEFT	•	1
123	Y-12117	BUSHING	•	2
124	23000-271	SIDE BURNER BODY	•	1

PARTS LIST / LISTE DES PIECES

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>8752-53NZ</u>	<u>8752-83NZ</u>
125	23000-253	SIDE BURNER COVER	•	1
126	10390-R81A	SIDE BURNER	•	1
128	23009-951	GRID	•	1
129	Y-11990	HEX NUT	•	1
130	27905-354	BURNER ROTISSERIE	•	1
133	S15278	ROTISSERIE HARDWARE	•	1
137	S15256	SPIT ROD	•	1
138	S15287	4 PRONG FORKS	•	2
139	20006-000	ROTISSERIE BRACKET	•	1
141	Y-11559	BOLT 1/4-20 X 1	2	2
142	S21125	SCREW #8 X 1/2	2	2
145	S21235	HINGE PIN	2	2
146	S21233	HITCH PIN CLIP	2	2
147	Y-11231	LID BUMPER	4	4
148	10240-20	DOOR PIN	2	2
149	Y-11551	SHOULDER SCREW 1/4-20 X 1	2	2
150	Y-12124	DOOR PIN CAP	2	2
151	Y-12857	WASHER	4	4
152	Y-12229	MAGNET	1	1
153	Y-12223	MAGNET - PUSH IN	2	2
155	S21124	SCREW #8 X 1/2	8	8
157	Y-12835	SCREW #6-32 X 1/4	•	2
158	Y-12641	SCREW #8-32 X 1/2	•	2
159	S21127S	SCREW #8-32 X 7/16	8	12
160	Y-29304	SCREW #10-24 X 3/8	10	10
161	Y-12310	SCREW 1/4-20 X 3/4	12	12
162	S21084	SCREW #14 X 5/8	8	8
167	Y-11981	BOLT 1/4-20 X 1	6	6
169	S21061	WING NUT	•	2
171	S15247	MOTOR	•	1
172	S15508	ELECTRODE	•	1
173	S21362	SPRING	•	1
180	S35095	SCREW #10-24 X 5/8	•	2
181	25030-73	WIRE - BATTERY PACK	1	1
181A	25070-95	LIGHT SWITCH	1	1
184	20025-803	BATTERY PACK	1	•
	20025-809	BATTERY PACK	•	1
186	Y-12865	SCREW 1/4-20 X 3/4	14	14
190	25020-84	WIRE - LED LIGHT	1	1
191	25020-82	WIRE - LED LIGHT	•	1

