

Broil King®


















Broil King
CROWN 420
8652-53NZ




Broil King
CROWN 490
8652-83NZ


HARDWARE INCLUDED

S21124		(4)	Y-29304		(2)
Y-12865		(12)	Y-11793		(4)
Y-11551		(2)	Y-12124		(2)
56039-214A		(1)	Y-12229		(1)
S21235		(2)	S21233		(2)
32001-151		(4)	S21084		(8)
S21125		(2)	 <p style="text-align: center;">#3 ROBERTSON #2 ROBERTSON</p>		
20005-000					(1)





TOOLS REQUIRED




1




2






3

(8) 








4




5

(2) 




2

1




6


(2)




(1)








7

(2) 



8




Proil King
BARBECUE



9

(4) 



(1)





(1)




10





11







13



(4)









15


(6)





16






17







18







20



(2)  (2) 




21



22





PARTS LIST / LISTE DES PIECES

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>8652-53NZ</u>	<u>8652-83NZ</u>
1	52005-107	FIREBOX ASSEMBLY	1	1
2	56005-801	LID ASSEMBLY	1	1
7	Y-11544S	SCREW - BURNER	4	4
8	S21242	BURNER CLIP	4	4
18	52001-981	COOKING GRID	4	4
20	52005-991	GRID - WARMING RACK	1	1
21	59805-014	CONTROL ASSEMBLY	1	•
	59805-074	CONTROL ASSEMBLY	•	1
22	22025-903A	COLLECTOR BOX	1	1
24	10111-16A	CONNECTOR HOSE	1	1
25	18631	BURNER	1	1
26	52002-298A	CONTROL KNOB	4	4
27	52001-298A	CONTROL KNOB	•	2
28	52025-124CRO	CONTROL COVER	1	•
	52025-304CRO	CONTROL COVER	•	1
31	52009-918	EDGE CAP - LH	1	1
32	52009-938	EDGE CAP - RH	1	1
34A	Y-11230	COTTER PIN	•	1
37	53139-908	SHELF BRACKET SUPPORT	4	4
38	Y-12620	SHELF LOCK CLIP	4	4
40	10111-HR06	REGULATOR	1	1
41	10342-E13	ELECTRODE	1	1
42	10342-E22	ELECTRODE	1	1
44	53005-001A	ELECTRONIC IGNITOR	1	•
	53005-007A	ELECTRONIC IGNITOR	•	1
44A	25070-925	WIRE - IGNITOR	1	1
44B	25070-931	BUTTON - IGNITOR	1	1
48	52004-007	DRIP PAN	1	1
49	51009-007	GREASE PAN	1	1
50	18431	GREASE RAIL	1	1
51	52009-104	FLAV-R-WAVE ®	4	4
52	52149-004	GREASE SHIELD	3	3
56	24005-12A	HANDLE	1	1
58	24009-936	BEZEL	2	2
59	10081-BK630	NAMEPLATE	1	1
60	18013	HEAT INDICATOR	1	1
62	53409-148	SHELF END CAP	2	2
65	20005-000	MATCH LIGHT - STICK	1	1
68	51275-111A	DOOR	1	1
69	51275-131A	DOOR	1	1
70	21071-13	HANDLE	2	2
71	21070-13	BEZEL	4	4
78	56039-214A	MAGNET BRACKET	1	1
80	51189-101A	SIDE PANEL	2	2
87	Y-11793	NUT 1/4-20	4	4
88	21305-921	PANEL - REAR	1	1
90	51625-131	BASE	1	1
99	32001-151	CASTOR BRACKET CAP	4	4
100	51639-108	CASTOR BRACKET	2	2
102	10892-286	CASTOR	4	4
103	21039-301	TANK BRACKET	1	1
113	10342-T14	SIDE BURNER ELECTRODE	1	1
114	53109-111	SHELF - RIGHT	1	1
115	53109-111	SHELF - LEFT	1	•
	53109-151	SHELF - SB - LEFT	•	1
123	Y-12117	BUSHING	•	2
124	53004-271	SIDE BURNER BODY	•	1
125	53000-251	SIDE BURNER COVER	•	1

PARTS LIST / LISTE DES PIECES

<u>KEY #</u>	<u>ITEM #</u>	<u>DESCRIPTION</u>	<u>8652-53NZ</u>	<u>8652-83NZ</u>
126	10390-E10E	SIDE BURNER	•	1
128	53009-951	GRID	•	1
129	Y-11990	HEX NUT	•	1
130	27905-354	BURNER ROTISSERIE	•	1
133	S15278	ROTISSERIE HARDWARE	•	1
137	S15256	SPIT ROD	•	1
138	S15287	4 PRONG FORKS	•	2
139	20006-000	ROTISSERIE BRACKET	•	1
141	Y-11559	BOLT 1/4-20 X 1	2	2
142	S21125	SCREW #8 X 1/2	2	2
145	S21235	HINGE PIN	2	2
146	S21233	HITCH PIN CLIP	2	2
147	Y-11231	LID BUMPER	4	4
148	10240-20	DOOR PIN	2	2
149	Y-11551	SHOULDER SCREW 1/4-20 X 1	2	2
150	Y-12124	DOOR PIN CAP	2	2
151	Y-12857	WASHER	4	4
152	Y-12229	MAGNET	1	1
153	Y-12223	MAGNET - PUSH IN	2	2
155	S21124	SCREW #8 X 1/2	4	4
157	Y-12835	SCREW #6-32 X 1/4	•	4
158	Y-12641	SCREW SHOULDER #8 X 1/2	•	2
159	S21127S	SCREW #8-32 X 7/16	8	12
160	Y-29304	SCREW #10-24 X 3/8	16	16
161	Y-12310	SCREW 1/4-20 X 3/4	12	12
162	S21084	SCREW #14 X 3/8	8	8
169	S21061	WING NUT	•	2
171	S15247	MOTOR	•	1
172	S15508	ELECTRODE	•	1
173	S21362	SPRING	•	1
180	S35095	SCREW #10-24 X 5/8	•	2
186	Y-12865	SCREW 1/4-20 X 3/4	14	14

